

CONVERT BATH™

Free Sizing Template & Template Instructions

(Please be sure to read entire instruction sheet before deciding to purchase your kit)

1. Take the template and place on top of the front wall of the tub; try to stay centered on the tub if you can. Take note where the arrow on the template should be pointing. Cut out the size template that appears to have the least amount of space between the tub and the template; as shown in the pictures. The large template comes in two parts: a page that has the Convertabath contact information listed and the page that shows two measurements of 4" both vertical and horizontal. The 4" measurement page is the top and the Convertabath information page is the bottom. Tape the bottom page up to the horizontal lines near the middle of the top page. This will create the template for the large kit. Take note of the size template you choose. **WHEN IN DOUBT, CHOOSE THE NEXT SIZE UP.**
2. After you cut out the template, fit the template over the tub wall to double check size. Again, you want to choose the size template that has the **LEAST** amount of space between the tub and the template.
3. The insert is approximately 28 ½ inches wide. Be sure to check template size and spacing for accurate fit on each end.
4. If one portion of the tub uses a smaller size than the other portion of the tub, you will choose the larger of the two sizes.
5. When the size has been determined, you may call or email us at (877) 944-BATH (2284) or info@convertabath.com and let us know what size (medium or large) best suits your tub.*
6. We will send you the kit plus an instruction manual and DVD. Please call for technical support if you have questions **prior** to installation so we can help you **prior** to the start of the job.

List of tools and materials that are needed are listed below.** The tools and install will make more sense when you get your kit:

Tools:

Caulking Gun
Pliers
Drill & Drill Bits
Chisels
Hammer
Sawzall & Metal Blades
Jig Saw & 2" Blades
Gloves
Stanley Knife
Screw Driver
2x4's
For cast iron tubs = 4 1/2" grinder
with diamond blade

Other Suggested Materials:

Paper Towels
Drop Cloths
Dust Masks
Ear Protectors
Eye Protector Glasses
Denatured Alcohol
Drain Screen
Masking Tape

**The consumer receives this sheet before deciding to purchase the kit in order to make sure they are aware of what is needed prior to purchase and installation. Once the kit is purchased, the consumer has 30 days to return the item for a refund, less shipping and handling and a 15% restocking fee. The kit cannot be returned and a refund will not be given if the insert has been installed and/or modified in any way or if any of the materials or containers have been used or opened. To receive a refund on a kit purchase, everything must be returned as it was originally shipped within 30 days of purchase.*

***The tools and materials are not included with the purchase of the kit. The consumer is responsible to purchase these items on their own if they do not already have them. Convertabath is not responsible for any items related to the kit except for what comes with the kit purchase: 1 insert piece, 1 adhesive/caulk tube, 1 cutting template, 1 DVD and 1 instruction manual.*